

Infrared Sauna Instruction Manual

Models MX-M206-01 FS (SJ-8223) / MX-M306-01 FS (SJ-8323)

2 and 3 Person Infrared Saunas



INFRARED MODEL SAUNA– with WiFi Capability

RED CEDAR MODELS

FOR INDOOR USE ONLY

120V/15AMP DEDICATED CIRCUIT REQUIRED FOR MX-M206-01 (SJ-8223)

120V/20AMP DEDICATED CIRCUIT REQUIRED FOR MX-M306-01 (SJ-8323)

Carefully and thoroughly read this Owner’s Manual before using/operating the sauna. We recommend keeping this Owner’s Manual for regular review and future reference. Follow your local codes and ordinances.

Table of Contents

Packing List	2
Assembly Diagram	6
Schematics	8
Schematic Layout	10
Dimensional Diagram	14
Screw Identification and Location Chart	18
Highlights	19
Assembly Instructions	20
Operating the Sauna	27
Maintenance	31
Tips for Using Your Sauna	32
Safety Instructions	32
Safeguards for Your Sauna	34
Troubleshooting Guide	35
Warranty	37
Warranty Registration	39

WARNING: Visually inspect all heaters before assembly to make sure they are not damaged. Any excessive vibrations during transport could cause damage to the heating elements. DO NOT START the sauna if damage is detected! Contact your dealer or manufacturer for troubleshooting and replacement parts.

Packing List (main panels):

1pc Front Panel	1pc Rear Panel	1pc Left Side Panel
1pc Right Side Panel	1pc Roof Panel	1pc Roof Cover
1pc Bench	1pc Bench Heat Emitter Panel	1pc Floor Panel

NOTE: Your model sauna has been completely assembled and tested prior to packaging. The rear wall panel is intentionally warped as part of the overall design. Two adults will be needed to assemble the sauna room.


The information provided in this Owner's Manual is for informational purposes only and may not be construed as medical advice or instruction. The information is not recommended for any particular treatment and in all cases, it is recommended that you consult with your medical physician before using. This product does not constitute or imply any medical endorsement.

CAUTION: Exit Sauna Immediately If You Feel Dizzy, Sleepy, Or Any Discomfort.

What Are Infrared Rays?

Infrared is the band of light we perceive as heat. We cannot see this band of light with the naked eye, but we can feel this type of light in the form of heat. Our sun produces most of its energy output in the infrared segment of the spectrum. Infrared rays heat your body without having to heat the air in-between. This process is called conversion.

The infrared is divided into 3 segments by wavelengths measured in microns: Near Infrared – 0.76-1.5 microns; Middle Infrared – 1.5-5.6 microns; and Far Infrared – 5.6-1000 microns. Among these segments, Far Infrared penetrates organic substances such as the human body two to three inches so that the warming effect is very uniform.



ARE INFRARED RAYS SAFE?

Because infrared rays are part of sunlight, they are not only safe but also highly beneficial to our bodies on a cellular level. Health professionals have used infrared heat lamps for decades to **treat muscle and joint problems**. In hospital baby care units, incubators are often equipped with infrared heating systems to **keep newborn babies warm**.

WHAT IS AN ELECTROMAGNETIC FIELD (also known as EMF)?

An Electromagnetic Field is a physical field produced by electrically charged objects. It is one of the fundamental forces of nature. The field can be viewed as the combination of an electric field and a magnetic field. The electric field is produced by stationary charges and the magnetic field by moving charges referred to as currents. The magnetic field is measured in milligauss (mG). Our sauna products have been developed to have low EMF. Our Low EMF carbon heater panels range between an average of 5mG-10mG at about two inches from the heater panel, our Ultra Low EMF carbon heater panels range between

3mG-5mG, and our Near Zero EMF carbon heater panels range at less than 3mG (NIR heaters range at about 5mG-7mG at the same approximate 2 inches)

EMF Levels from Common Homes Sources

SOURCE	mG up to 4 inches	mG at 3 feet
Blender	50-220	0.3-3
Clothes Washer	8-200	0.1-4
Coffee Maker	6-29	0.1
Computer	4-20	2-5
Flourescent Lamp	400-4,000	0.1-5
Hair Dryer	60-20,000	0.1-6
Microwave Oven	100-500	1-25
Television	5-100	0.1-6
Vacuum Cleaner	230-1,300	3-40
Airplane	50	
Source: USA Environmental Protection Agency		


After many years and numerous studies on EMF exposure, no government body including the Occupational Safety and Health Administration (OSHA) have established permissible exposure limits (PEL). Currently, there is no consensus on the potential health hazard from any exposure to EMF. The mainstream scientific evidence suggests that low-power, low-frequency, electromagnetic radiation associated with household currents like that of the infrared sauna does not constitute a short- or long-term health hazard.

DISCLAIMER

The infrared rays emitted by your sauna are reported to offer a wide range of possible therapeutic benefits based on research completed over the last 40 years from all around the world. These benefits are presented for reference purposes only and no implication of infrared saunas creating a cure for or treating any disease is implied nor should it be inferred. If you have a medical/health condition, are taking prescription drugs, or have acute joint injuries, please consult with your medical physician before using the sauna. Persons with surgical implants (metal pins/rods, artificial joints, silicone, or other types of surgical implants) typically do not experience any adverse effects, but should also consult their medical physician or surgeon before using the sauna room.

HOW IT WORKS

Infrared Saunas differ from traditional saunas in that they use infrared radiant energy to directly penetrate into the body's tissue to produce perspiration. Traditional saunas use steam to heat the air inside the sauna, which then heats your body until you begin to perspire. In order for this to be effective, temperatures would need to reach in the upwards of 190 degrees Fahrenheit. Infrared saunas only need a temperature of up to 120 degrees Fahrenheit to obtain the same effect. This lower temperature makes the environment more tolerable and allows you to breathe easier.



Health Benefits

Because infrared rays penetrate the body through convection, there is a deep heating effect in both the muscle tissues and internal organs without putting too much burden on the heart.

Our body reacts to the increased heating through the natural cooling process of perspiring. Through the perspiration process, acid and waste residue like toxins, sodium, alcohol, nicotine, cholesterol, and the potentially carcinogenic heavy metals are removed from the cells (especially zinc, lead, nickel, cadmium, etc.). The pores of our skin open and discharge waste products shedding any old skin cells leaving the skin glowing and clean, with improved tone, elasticity, texture, and color.

Health Benefits Include, But Are Not Limited To:


- | | | |
|--|---------------------------|---------------------|
| *Pain relief from Rheumatoid Arthritis | *Relaxes muscle spasms | *Reduces cellulite |
| *Increases blood circulation | *Clears, rashes, acne | *Enhances skin tone |
| *Cardiovascular conditioning | *Reduces stress & fatigue | *Removes toxins |

Sauna Maintenance

Since infrared saunas do not require hot rocks, water, or steam to operate, they require very little maintenance. You can simply wipe it down with water – use a damp, soft, and clean cloth. **Do not use any chemical-based cleaning agents** as they can be absorbed into the wood and be released into your sauna during use.

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY


MX-M206-01 FS (SJ-8223) – Assembly Diagram



***THE ABOVE ASSEMBLY DIAGRAM IS FOR A QUICK REFERENCE VISUAL GUIDE ONLY. ALL SAUNA MODELS MAY NOT BE SHOWN. PARTS AND ACCESSORIES DO VARY AND ARE SUBJECT TO CHANGE. BACKRESTS NOT INCLUDED.**

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY

MX-M306-01 FS (SJ-8323) – Assembly Diagram




***THE ABOVE ASSEMBLY DIAGRAM IS FOR A QUICK REFERENCE VISUAL GUIDE ONLY. ALL SAUNA MODELS MAY NOT BE SHOWN. PARTS AND ACCESSORIES DO VARY AND ARE SUBJECT TO CHANGE. BACKRESTS NOT INCLUDED.**

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY

MX-M206-01 FS (SJ-8223) – Schematics

Electronic components			
No.	Name	No.	Name
1	Power supply	2	LED DC exterior lights
3	Speakers	4	Big color light with red light therapy
5	MP3 Jack	6	Temp Sensor
7	N2022 touch screen		

Power layout			
Location	No.	Dimension	Power
Left wall panel	8	680*400mm=1PCS	300W
Right wall panel	9	680*400mm=1PCS	300W
Rear wall panel	10	NIR heater =2PCS	300W
Heater bench panel	11	1000*300=1PCS	200W
Floor heater	12	1000*340=1PCS	300W
TOTAL			1700W




***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE. BACKRESTS NOT INCLUDED.**

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY

MX-M306-01 FS (SJ-8323) – Schematics

Electronic components			
No.	Name	No.	Name
1	Power supply	2	LED DC exterior lights
3	Speakers	4	Big color light with red light therapy
5	MP3 Jack	6	Temp Sensor
7	N2022 touch screen		


Power layout			
Location	No.	Dimension	Power
Left wall panel	8	680*400mm=1PCS	300W
Right wall panel	9	680*400mm=1PCS	300W
Rear wall panel	10	NIR heater =3PCS	300W
Heater bench panel	11	1000*300=1PCS	300W
Floor heater	12	1000*340=1PCS	300W
TOTAL			2100W



***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE. BACKRESTS NOT INCLUDED.**

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY


MX-M206-01 FS (SJ-8223) – Schematic Layout



***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE.**

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY


MX-M206-01 FS (SJ-8223) – Schematic Layout (cont'd)




***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE.**

READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY


MX-M306-01 FS (SJ-8323) – Schematic Layout



Roof wall panel



Right side wall




Front wall panel

***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE.**


READ ALL INSTRUCTIONS THOROUGHLY BEFORE ASSEMBLY

MX-M306-01 FS (SJ-8323) – Schematic Layout (cont'd)




***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE.**

MX-M206-01 FS (SJ-8223) – DIMENSIONAL DIAGRAM




Roof wall panel




Front wall panel

MX-M206-01 FS (SJ-8223) – DIMENSIONAL DIAGRAM (cont'd)




***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE.**

MX-M306-01 FS (SJ-8323) – DIMENSIONAL DIAGRAM




Roof wall panel




Front wall panel

MX-M306-01 FS (SJ-8323) – DIMENSIONAL DIAGRAM (cont'd)



left side wall panel



Rear wall panel

***THE PICTURES AND DIAGRAMS SHOWN WITHIN THIS OWNER'S MANUAL ARE REPRESENTATIONS OF THIS MODEL. ACTUAL MODEL MAY VARY. DESIGN AND CONSTRUCTION ARE SUBJECT TO CHANGE.**


SCREW IDENTIFICATION AND LOCATION CHART

MODEL: MX-M206-01		
LOCATION	SPECS	USAGE
Bench	5*50mm (Color plating)	4
Roof panel	5*50mm (Color plating)	5
Roof dust cover	3*18mm (Color plating)	12
Floor heater panel	4*35mm (Color plating)	4
Interior handle	4*60mm (Color plating)	2
Door handle spacer	20*20*1mm(Plastic)	4
MP3 Jack	4*25mm (Color plating)	2

MODEL: MX-M306-01		
LOCATION	SPECS	USAGE
Bench	5*50mm (Color plating)	4
Roof panel	5*50mm (Color plating)	5
Roof dust cover	3*18mm (Color plating)	16
Floor heater panel	4*35mm (Color plating)	4
Interior handle	4*60mm (Color plating)	2
Door handle spacer	20*20*1mm(Plastic)	4
MP3 Jack	4*25mm (Color plating)	2

Highlights

- A. High quality craftsmanship
- B. Temperature control
- C. Timer
- D. Infrared carbon heat emitter panels
- E. Control Panel:




- F. Power supply and sub power supply:



- G. MP3 Jack:



- H. Buckles:



Assembly Instructions

Please note that your sauna has been completely assembled and tested at the factory prior to packaging. Please further note that the rear wall panel is intentional warped as part of the overall design. Two adults will be needed to assemble the sauna room.

- A. You will need a philips screwdriver, ladder, and two adults to assemble.
- B. Do not plug any other appliances into the power supply of the sauna room other than the designated sauna connections/plugs.
- C. Assemble the sauna room on a completely level surface. You will need to walk around the sauna room during assembly. Once assembled, we recommend a 1" to 2" clearance around the sauna room and a 10" to 12" clearance above the sauna room. If you need to push the sauna room into place, be sure to do so at the base of the sauna room.
- D. Do not spray or get water on the exterior/interior walls of the sauna room. If the floor is damp, install a floor separator to keep the sauna high & dry.
- E. Do not store flammable objects or chemical substances near the sauna.

Sauna Room Assembly:

- 1. Structure of Infrared Sauna. **See pages 6-9.**
- 2. Make sure all parts are present before installing the unit. See packing list below.
 - A. Front Panel B. Floor Panel C. Back Panel D. Left Side Panel
 - E. Right Side Panel F. Bench G. Bench Heater Panel H. Roof Panel
 - I. Roof Dust Cover J. Floor Heater K. Handle
- 3. 2-person sauna models are packed into two cartons and 3-person sauna models are packed into three cartons. For example: C/NO: A = A OF AB and C/NO: C = C OF ABC. **See FIG-1**




FIG-1 Cartons

4. Place the Floor Panel on a smooth/flat surface and make sure which side is the front and which side is the back. The front of the floor will have a slant. The back does not have a slant. **See FIG-2**



FIG-2 Placing Floor Panel

5. Place the Back Panel up and onto the Floor Panel. One adult will need to hold the Back Panel while the other adult continues to the next step. **See FIG-3**




FIG-3 Assembling Back Panel

6. Align the Left Side Panel with the Back Panel. Be sure to make sure the Left Side Panel fits flush into the Back Panel. **See FIG-4 and FIG-5**



FIG-4 Assembling Left Side Panel




FIG-5 Buckle

7. Latch the Left Side Panel with the Back Panel. The buckle has a guide tab that must be placed in the guide slot for alignment. When the Back Panel and the Side Panel are attached together on the Floor Panel, make sure all the buckles are latched tight. **See FIG-4 and FIG-5**

8. Align the Right Side Panel with the Back Panel. Be sure to make sure the Right Panel fits flush into the Back Panel and latch together. **See FIG-6**




FIG-6 Assembling Right Panel

9. Latch the Right Side Panel with the Back Panel. The buckle has a guide tab that must be placed in the guide slot for alignment. When the Back Panel and the Side Panel are attached together on the Floor Panel, make sure all the buckles are latched tight. **See FIG-4 and FIG-5**
10. Place the Floor Heater on the Floor Panel making sure that the Floor Heater will be in front of the Bench Heater Panel. Please note there is a pre-cut small hole under the Bench Heater Panel which is provided for the Floor Heater cord to pass through. This cord will connect the Floor Heater to the plug outlet on the Left Side Panel. **See FIG-7 and FIG-8**



FIG-7 Floor Heater Assembly





FIG-8 Connect Floor Heater

11. The Bench Heater Assembly will need to be installed at an angle and brought forward. **See FIG-9.** Connect the Bench Heater Panel cord with the outlet on the Back Panel and then place the Bench on top of the Bench Heater Panel and slide it into place. Make

sure the cords are connected snug and tight. You can use the provided screws to secure the bench in place. You may need to remove the protection grid on the rear wall panels to screw down the bench. Proceed to screw the Floor Heater down with the provided screws at least 3 inches in front of the Bench Heater Panel.



FIG-9 Bench Heater Assembly

12. Place the Front Panel up and onto the Floor Panel and align it with both the Left and Right Side Panels. Next, latch the Front Panel with the Left and Right Side Panels respectively. Note: Be cautious with the glass door to avoid breakage. **See FIG-10**



FIG-10 Assembling Front Panel

13. The buckle has a guide tab that must be placed in the guide slot for alignment. When the Front Panel and the Side Panels are attached together on the Floor Panel, make sure all the buckles are latched tight. **See FIG-4 and FIG-5**

14. Place cords/wires of Front Panel, Back Panel, and Side Panels into the sauna room area to avoid damaging the cords/wires during the roof installation. Open the door, lift the Roof Panel up and over the sauna room and gently lower it into place resting it on the wall panels. Make sure that all cords/wires are slipped through the corresponding holes in the Roof Panel. Screwing the Roof Panel down is optional. **See FIG-11 and FIG-12**



FIG-11 Slip cords/wires through corresponding holes



FIG-12 Connecting cord connectors

15. Connect the control panel connectors. **See FIG-13**




FIG-13 Connecting control panel connectors

16. Make sure all steps are completed correctly. Plug in the power cord to your wall outlet. Turn on the sauna at the control panel to confirm that the control panel is responding. If the control panel responds accordingly, then proceed in putting the Roof Dust Cover onto the Roof Panel. Please note that installing the Roof Dust Cover is optional. By not installing it, the power supply cools down faster, possibly extending the life of the power supply. You can pull the power cord through the corresponding hole in the Roof Cover. **See FIG-14**





FIG-14 Roof Dust Cover Assembly

17. Attach the door handle and screw into place. **See FIG-15**




FIG-15 Door Handle Installation

Assembly Completed.

Operating the Sauna

NOTE: Please check and confirm that the connections to the **POWER SUPPLY**, **HEAT EMITTERS**, and **TEMPERATURE SENSOR** are connected properly. The power supply voltage and frequency must match the requested voltage and frequency of the sauna (120VAC 15AMP Dedicated Circuit or 120VAC 20AMP Dedicated Circuit). This is a residential /semi-commercial appliance. For every (3) hours ON, the unit must have (1) hour OFF.

Since many materials absorb the infrared rays, minimal clothing is recommended for maximum effect. The infrared sauna emitters are designed to heat you and not necessarily the air inside the sauna. It is not a hot box like a traditional sauna. The temperature gauge is a guide for your safety. It is recommended that you drink water before, during, and after sauna use to prevent dehydration since body fluids will be lost through perspiration. It is not recommended to shower after use since the pores in your skin will be open and could possibly absorb anything in the water.




1. Control Panel Operation:

- A. Standby Status:** While the system is in Standby Status, press and hold any area on the control panel display screen for approximately (5-7) seconds. This will activate the display screen to come out of Standby Status and the display screen will come ON. You will see “Hello + WiFi” on the display screen and after about (5) seconds, the display screen will enter the main control interface mode as seen above. You must always physically turn the Control Panel OFF after each use. When you press the “Power Off”, the system will enter the

shutdown mode. Proceed to press the “OK” button and the complete sauna will turn OFF.

B. Start Sauna: Make sure that the display screen is in the control interface mode.

Press the “” button and the system will enter the heating mode. Press the “” to Start/Stop the sauna’s heating. If the icon is red, then the heating is stopped. If the icon is green, then the heating is activated.



C. Temperature Setting: To set/adjust the temperature, press the “” or “”. You can also drag the horizontal bar “” up/down to set/adjust the temperature setting as well. The range is between 86°F/30°C - 150°F/65°C. The average used temperature range is between 118°F/48°C – 122°F/50°C. The average sauna session is approximately 20 – 30 minutes. **It is recommended that you pre-heat the sauna room to the desired temperature before entering.** Note: If the ambient temperature is below 68°F/20°C, the sauna will take longer to pre-heat. It is not recommended to use the sauna in an environment with an ambient temperature below 60°F/16°C.

D. Time Setting: To set/adjust the time, press the “” or “”. You can also drag the horizontal bar “” up/down to set/adjust the time setting as well. The range is between 1 minute – 90 minutes. As a safety feature, the control panel will turn OFF if the screen is not touched within 105 minutes.

E. You can press the “” to return back to the main interface mode.

F. Light: To enter the Light mode, press the “ Lights “.



Either the Red Light Therapy or the Interior Lights can be ON at any given time. They cannot be operated simultaneously.

1. Press the “ “ button to turn ON/OFF the Exterior Lights (DC12V).
2. Press the “ “ button to turn ON/OFF the Red Light Therapy (DC12V).
3. Press the “ “ button in order to turn ON/OFF the Interior Lights (DC12V).
You can press any of the colored icons when the interior light is in the ON mode.



4. Press the “ “ button and the color light will go through a sequence of colors.

G. Audio: Press the “ Audio “ button to enter the music interface mode. Press the “ FM Radio “ to enter the radio function. You can use the “ “ or “ “ to scroll through the radio stations. Please note that you may only be able to receive limited radio stations. Press the “ AUX “ button in order to use the AUX mode. Press the “ BT “ button in order to use the

Bluetooth mode. In addition, you can drag the “” vertical bar from side-to-side to adjust the volume.



- H. You can press the “” to return back to the main interface mode.
- I. For WiFi connection to remotely turn ON/OFF the sauna, please see the “Sauna WiFi Operational Instructions” included separately from this Owner’s Manual.
- J. Drink water prior to, during, and after your sauna session to replenish body fluids.
- K. After 3 hours of continuous use, the sauna needs to be shut down for one hour.
- L. To avoid burns, do not touch the heating element or let anything come into contact with the heaters.

Please Note: On average, it takes our model saunas approximately:

- *20 minutes to reach into 100 degrees Fahrenheit/38 degrees Celsius (with a starting temperature above 70 degrees Fahrenheit/21 degrees Celsius)**
- *25-30 mins to reach about 115-120 degrees Fahrenheit/46-49 degrees Celsius (depending on sauna model)**
- *35-40 minutes to reach about 125-130 degrees Fahrenheit/52-54 degrees Celsius (depending on sauna model)**
- *45-60 minutes to reach up to approximately 135 degrees Fahrenheit/57 degrees Celsius (depending on sauna model)**

Please keep in mind that you can either preheat the sauna to the set temperature before entering or sit inside the sauna as the temperature rises. In addition, you will

increase the time it takes for the sauna to reach the set temperature if you enter the sauna room before it has reached the set temperature. Also, the most commonly used temperature setting is between 118 degrees Fahrenheit / 48 degrees Celsius and 122 degrees Fahrenheit / 50 degrees Celsius. The way the sauna room works is when you set the Control Panel to say 120 degrees F / 49 degrees C, the heat emitters will turn off when that set temperature is reached. And even though the sauna does allow the user to set the Control Panel to the maximum temperature, this is specifically for those users who do not want the heaters to ever turn off as the sauna room will never achieve up to the maximum set temperature. After 3 hours of continuous use, the sauna needs to be shut down for one hour.

If for any reason the temperature reaches up to 185 degrees Fahrenheit / 85 degrees Celsius, the display screen will show “Over Temperature” and all functions of the sauna will shut down as a safety feature for the sauna to be inspected for abnormality. Once the issue is determined, corrected, and when the temperature falls below 149 degrees Fahrenheit / 65 degrees Celsius - the control panel will need to be turned OFF and back ON again to resume its normal function.

Use 2 towels during your sauna session. Fold the first towel several times and place it on the bench. As you sit on this towel, it will absorb a majority of your perspiration while adding comfort as you sit on the bench. Use the second towel to either constantly wipe the perspiration from your body to perspire faster and also to avoid having too much perspiration dripping onto the floor. Never place any towels over the floor heater. If your legs become cold, you can use a third towel to drape over your legs to trap the heat.

Maintenance

Do not use liquid cleaners or aerosol cleansers inside the sauna. Unplug the sauna from the wall outlet before cleaning. Use plain water and a soft cloth for cleaning. Clean floor and floor heater regularly to keep free of debris. ***Do not use benzene, alcohol, or strong cleaning chemicals in or on the sauna. NOTE: Any chemical that can damage wood or be absorbed into the wood will damage the sauna.***

CAUTION: Average used temperature range is between 120 degrees F – 130 degrees F. Exit sauna immediately if you feel dizzy, sleepy, or any discomfort.

Tips for using Your Sauna

1. If you take a hot/warm shower or bath before using your sauna, you may perspire more and experience more comfort.
2. Drink water prior to, during, and after your sauna session to replenish body fluids.
3. To regulate the set temperature inside the sauna to your comfort level, use the movable roof vent or leave the door slightly open. The roof vent is installed on the sauna and used based on personal preference.
4. Use 2 towels during your sauna session. Fold the first towel several times and place it on the bench. As you sit on this towel, it will absorb a majority of your perspiration while adding comfort as you sit on the bench. Use the second towel to either constantly wipe the perspiration from your body to perspire faster and also to avoid having too much perspiration dripping onto the floor. Never place any towels over the floor heater. If your legs become cold, you can use a third towel to drape over your legs to trap the heat. Do not allow sweat puddles to develop onto the floor panel.
5. This is a non-commercial sauna. For every three hours ON, the sauna must be turned OFF for one hour to cool down.
6. At the first sign of a cold or flu, increasing your sauna sessions may be beneficial in boosting your immune system and decreasing the reproductive rate of the virus.
7. To help relieve sore and tense muscles, massage the affected areas during your sauna session.
8. To treat your ankles and feet more effectively, you can elevate them and move them close to one of the heat emitters to achieve a deep heating effect.
9. To utilize the sauna's heat therapy effect, put oil and treatment into your hair and wrap it with a towel. After your sauna session is over, rinse your hair thoroughly.
10. The peaceful and relaxed state rendered by a sauna session may help you to sleep easier and deeper.
11. To conserve energy consumption, please unplug your sauna when not in use – especially if you do not plan on using the sauna for an extended period of time.
12. After the sauna session is over, do not jump into the shower or bath immediately. Because your body was heated up during the sauna session, it will continue to perspire even after the heat emitters are off. Sit in the sauna with the door slightly opened and let your body cool down. Once your body has cooled down and you feel comfortable, you can exit the sauna. After about fifteen minutes and when your body has completely cooled down, you can take a shower or bath to clean your body.

Safety Instructions

1. Read and follow all instructions carefully before using the sauna.
2. When assembling and using the electrical equipment, safety precautions should always be followed.
3. To reduce the risk of injury, do not allow children to use the sauna unless they are closely supervised at all times by an adult. Children should not use the sauna unless prescribed or advised by their medical doctor.

4. Do not use the sauna immediately following strenuous exercises. Wait at least 30 minutes to allow the body to cool down completely.
5. Pregnant or possibly pregnant women should contact their medical physician prior to using the sauna. Excessive temperatures have a high potential for causing fetal harm during pregnancy.
6. **Hyperthermia Danger:** The normal body temperature can't rise above 103°F (39°C). Symptoms of excessive hyperthermia include dizziness, lethargy, drowsiness, and/or fainting. The effects of excessive hyperthermia may include, but are not limited to failure to perceive heat, physical inability to exit the sauna, unawareness of impending hazards, unconsciousness, and/or fetal harm in pregnant women. Hyperthermia could make your body's core temperature rise. Setting the desired temperature to an excessively high temperature is not recommended.
7. The use of alcohol, drugs, or medications (prescribed or non-prescribed) prior to or during the sauna session may lead to unconsciousness and/or other harmful physical injuries.
8. Persons suffering from obesity or with a medical history of heart disease, low or high blood pressure, circulatory system problems, diabetes, or other medical conditions should consult with a medical physician prior to using the sauna.
9. Persons using medications should consult with a medical physician before using the sauna. Some medications may induce drowsiness while other may affect the heart rate, blood pressure, and/or blood circulation.
10. Use care when exercising before and after sauna use.
11. Never sleep inside the sauna
12. Do not use any type of cleaning agents on the interior of the sauna. Only wipe down the sauna room with water and a damp cloth. Never use any chemical based cleaners.
13. Do not stack or store any objects on top of or inside the sauna.
14. If the power supply cord becomes damaged, it must be replaced immediately by the manufacturer or its agent. If you find the power cord is too hot (normally it will become warm) or that the electrical equipment may be experiencing technical problems, please contact the manufacturer or its agent immediately to avoid hazardous situations.
15. Make sure that the electrical outlet is in good working order. A common problem with electrical outlets is loose wiring on the connection points of the terminals of the outlet. A loose wire will also make for a bad connection and cause an unusual amount of heat buildup. Loose connections can also cause sparking in the junction box that can result in arcing. You'll likely see burn marks around the terminals if this occurs. If this happens, do not use the sauna and have the outlet replaced by a certified electrician. If the power cord is damaged, please contact Customer Support.
16. Do not use the sauna during an electrical storm to avoid risk of shock or injury.
17. Do not continuously switch the power ON and OFF excessively as it will compromise the life of the electrical components.
18. Your hands must be dry and free of moisture before plugging and unplugging cords and wiring harnesses from the power supply and circuit boards. Never operate the sauna with wet hands or wet feet to avoid the risk of electrical shock or injury. Never touch the metal prongs of the plug.

19. Do not attempt to make any repairs yourself unless authorized by the manufacturer or its agent. If a problem occurs with the sauna, please contact the manufacturer or its agent immediately to avoid safety risks. Unauthorized repair attempts will void the manufacturer's warranty.
20. Please make sure the outlet power supply meets the specifications required. Failure to meet the requirements may cause safety risks.
21. Some sauna models are equipped with reading and/or roof lamps. Because the lamp temperature will become very hot once powered ON, do not attempt to touch the lamp to avoid being burned. Do not attempt to touch it for at least 20 minutes or until it cools down completely if a need to touch it arises.
22. Do not pour water or any other liquids onto the infrared heat emitters. Do not bump, hit, or break the heating elements as it may cause an electrical short and pose a safety risk.
23. Do not make any modifications to the sauna, the sauna structure, or the sauna components.
24. Prior to each sauna session, the sauna room is to be inspected for correct operation. If for any reason your sauna does not seem to be operating properly, discontinue use and contact Customer Service.

Safeguards For Your Sauna

1. Do not install the sauna near water, near a bathtub (if water will splash on the sauna), near a shower (if water will splash on the sauna), in a wet basement, or near a swimming pool (if water will splash on the sauna).
2. Do not use liquid cleaners or aerosol cleaners on the sauna. Unplug the sauna from the wall outlet before cleaning. Use plain water and a soft damp cloth for cleaning.
3. The power supply cord should be routed so that it is not walked on or pinched by any object that may be placed against it.
4. When replacement parts are required, be sure they meet the specified requirements of the manufacturer. Unauthorized substitutes may result in a fire, electrical shock, or other hazardous situations. After any repairs, please ask the service technician to perform a safety check to determine that the sauna is in good working order.
5. Do not use any wall receptacle adapter, surge protector, or extension cord between the sauna cord and wall outlet.

Troubleshooting

	problem	possible reason	Solution
1	Power Supply is showing no signs of power	The power cord is not plugged in properly	Disconnect/reconnect the power cord connection at the wall outlet
		No power at the wall outlet	Check your circuit breaker to confirm power at the wall outlet
			Replace the power supply
2	Control panel is not working	The CTRL harness on the rooftop is not connected properly	Disconnect/reconnect the CTRL harness on the rooftop
		The CTRL harness behind the display screen is not connected properly	Disconnect/reconnect the CTRL harness at the backside of the control panel
			Replace the control panel
3	After heaters work for a period of time and then the heating stops (display screen shows “Open Circuit” or Short Circuit”)	Circuit breaker trips	Check your in home circuit breaker at the electric panel
		System overload; overcurrent protector activated	Check first for an open circuit; if not, check power supply reset button
		Temperature sensor overheating	Check for overheating
		Power supply issue	Check if the control panel is working; if so, then the power supply will need to be replaced
4	Abnormal control panel	Defective control panel	Disconnect/reconnect the CTRL harness at the backside of the control panel
5	System alarm	Control panel displays “EO” and hear warning	Sensor has open circuit
		Control panel displays “HH” and hear warning	Over temperature issue; check power is 120V
		Control panel displays “E1” and hear warning	Sensor short circuit
6	Bluetooth pairing failure	Another device is paired	Unpair previously paired device
		Bluetooth version on device is not compatible with sauna control system; supports 2.0 or 4.0	Use compatible Bluetooth version
		Bluetooth module failure	Replace power supply

7	No sound from speaker	Speaker wire disconnected	Connect speaker wire on the rooftop
8	Abnormal temperature display	Damaged temperature sensor	Replace temperature sensor
9	Speaker does not work	The speaker is broken	Replace with a new one of the same specifications
		The speaker wire is loose	Disconnect and reconnect the speaker connections
		The power indicator light for CD is off	Turn on the switch to start work
10	Floor heater malfunction	Too much sweat buildup	Use towels per the instructions to prevent sweat puddles
		Too much sweat/debris buildup	Clean the floor panel regularly per maintenance instructions
		Floor heater smoking	Cause would be too much sweat/debris buildup; Contact manufacturer
		Not heating	Make sure floor heater is clean; disconnect/reconnect floor heater power cord
11	WiFi not working	Connection not made on rooftop	Connect WiFi box connection on rooftop

Limited Lifetime Warranty

5 Year Limited Warranty*: Golden Designs, Inc. under the Maxxus brand name warrants the wood, structure, heating elements, and electronics against defects in material and workmanship for a period of 1 to 5 years from the original date of purchase.

This sauna is for INDOOR use only. Placing your sauna outdoors will VOID this warranty. Any damage due to exposure to outdoor elements such as rain, snow, sun, wind or extreme temperatures will not be covered by this warranty. Any damages as a result of modifications made to the sauna or its components will void this warranty.

Extent of Warranty: This limited warranty applies to products manufactured or distributed by Golden Designs, Inc. under the Maxxus brand name, delivered in the continental United States or Canada and extends to the original purchaser at the original site of installation only. This warranty becomes valid at time of purchase and terminates either by specified time frame listed above, owner transfer, or relocation. **Your sales receipt showing the date of purchase of the product is your proof of purchase. Warranty is not transferable.**

Manufacturer Warranty

All Golden Designs, Inc. products are manufactured with the highest quality appliances and are warranted to be free from defects in material and workmanship at the time of delivery. The appliance warranty is extended through the manufacturer for the product including, but not limited to: stereos, CD/DVD players, etc. All exchanged parts and products replaced under this warranty will become the property of Golden Designs, Inc. Golden Designs, Inc. reserves the right to change manufactures of any part to cover any existing warranty. Any parts determined to be defective must be returned to Golden Designs, Inc. to obtain warranty service. You must prepay any shipping charges, export taxes, custom duties and taxes, or any other charges associated with the transportation of the parts. In addition you are responsible for insuring any parts shipped or returned. You must present Golden Designs, Inc. with proof of purchase documents (including the date of purchase). Any evidence of alteration, erasing or forgery of proof of purchase documents will be cause to **VOID** this limited warranty. Products on which the serial number has been defaced or removed is not eligible for warranty service. This warranty covers parts, but does not cover labor.

Warranty Limitations

This warranty does not apply if the unit has been subject to negligence, alteration, modification, misuse, abuse, repairs by non-Golden Designs, Inc. authorized personnel, inappropriate installations, or any case beyond the control of Golden Designs, Inc. invalidating this warranty including but are not limited to:

- Use of lacquer or paints
- Sauna and other Golden Designs, Inc. products accessories placed on non-approved surfaces

- Outdoor applications
- Normal wear and tear or weathering
- Use of product not in accordance with instructions
- Worn out receptacle

Surface cracks are not considered defects in material or workmanship, as they are normal characteristics of all woods. This includes minor cracks due to wood expansion and contraction. Note: Since the wood used in construction has been kiln dried, a certain amount of expansion and contraction occurs in the wood in a sauna environment.

When adding the WiFi feature, it allows for the sauna to be turned on remotely while not being monitored. Any potential liability arising out of the use of the WiFi feature would be solely at the sauna owner's risk.

Disclaimers

Golden Designs, Inc. shall not be liable for loss of use of sauna or other Golden Designs, Inc. products or other secondary or incidental or consequential costs, expense or damages - which may include the removal of permanent deck or other custom fixtures or the necessity for crane removal - arising directly or indirectly out of the use or inability to use the product. Any implied warranty shall have duration equal of the applicable warranty stated above. Under no circumstances shall Golden Designs, Inc. or any of its representatives be held liable for injury to any person or damage to any property, however arising. Specifications are subject to change without notice or obligation.

Legal Remedies

This limited warranty gives you specific legal rights. You may have other rights, which may vary from state to state.

Customer Service

For customer service, contact your authorized dealer. If you need additional information or assistance, please email Golden Designs, Inc. at info@goldendesignsinc.com or call (909) 212-5555.

*Limited Lifetime Warranty of Sauna Products is 5 years for residential use and 1 year for commercial use on heating elements and electronics from the date of purchase. The wood structure has a 1 year limited warranty.

WARRANTY REGISTRATION

Congratulations on your purchase of an Infrared Sauna from Golden Designs, Inc. Please take the time to register your warranty using the QR Code:



If you do not have the QR Code Reader, you can also register at:

<https://app.goldendesigninc.com/public/RegisteredProduct>

Please include a copy of your sales receipt or packing slip when registering. The serial number (S/N) is located on the sauna's front panel, rear panel, or on the carton.

The warranty must be registered within 60 days of the purchase date.

